



- when it has to be **right**

Leica
Geosystems

Leica Viva Quick Guide Determine Coordinate System using Multiple Points






This guide is designed to enable the user to create a co-ordinate system on System Viva, for a site which already has a local grid system in place, having existing points with known co-ordinates able to be surveyed with the GPS sensor, typically survey control stations. It is based upon a 'One-Step' method which is suitable for sites up to 10km in length.




Leica Geosystems Ltd
Davy Avenue, Knowlhill
Milton Keynes. MK5 8LB
Technical Support Phone. +44 1908 256 529
Email: uk.support@leica-geosystems.com
www.leica-geosystems.co.uk

- Leica Viva Quick Guide
 - Determine Coordinate System using Multiple Points




Step	Instruction	Screenshots
1.1	<p>From the main job screen, use the following buttons to access Determine Coordinate System.</p> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px; text-align: center;"> Go to Work! Survey & stake pts Start base station </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px; text-align: center;"> Survey+.. </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> Determine coord sys </div> </div> <p>Select the Onestep method for sites up to 10km in length.</p>	
1.2	<p>Input a name for the Coordinate system to be created. Since the coordinate system will be site specific, it is recommended to incorporate the site name, eg <SITE NAME> LOCAL SYSTEM. For matching multiple points, leave the <Use one pt localisation method> button unchecked.</p> <p>Select or define the job in which the GPS surveyed points are stored (WGS84 Points Job) and the job in which the local grid coordinated points are stored. If you can't find the job by scrolling through, then press enter to change the storage device</p>	
1.3	<p>The job location is shown in the blue location bar, in this case Int Mem. F6 allows the user to toggle between CF card, USB stick, SD card to locate your job. Alternatively a new job can be created using F2 <New>. Job data can be viewed using F5 <Data>, and new points can be added here also if required.</p>	

	Press <OK> to continue.	
--	-------------------------	--

Step	Instruction	Screenshots
1.4	<p>Pressing F2 <Config> will let you define the size of residuals to be flagged.</p> <p>Press <OK> to continue.</p>	
1.5	<p>Set height mode. If a local height datum is being used, set this to Orthometric. If a Geoid model is to be used, set to Ellipsoidal.</p> <p>Press <OK> to continue.</p>	
1.6	<p>If a Geoid model is to be used, select it here</p> <p>Press <OK> to continue.</p>	

Step	Instruction	Screenshots
1.7	<p>This is where GPS surveyed points are matched to the corresponding point with known local grid coordinates. Press F2 <New> to add points one by one.</p> <p>*Note: If the WGS84 job and local job have identical point ID's, then F6 <Auto> will match these automatically.</p>	
1.8	<p>Select the point ID's to be matched.</p> <p>With WGS84 Point highlighted, pressing enter will give the user the opportunity to survey a position at this time.</p> <p>With Local Point highlighted, pressing enter will give the user the opportunity to create/input new local coordinated points.</p> <p>Select the elements to be matched, e.g. height only for site datum mark.</p> <p>Press <OK> to continue.</p>	
1.9	<p>Continue until all your points are matched. <Edit> to make any changes to the points, <Delete> to remove the points from the solution, <Match> to toggle through the Matched elements (e.g. Pos. & Ht., Pos Only, Ht. Only).</p>	

	Press F1 <Calc>.	
--	------------------	--

Step	Instruction	Screenshots																					
1.10	<p>The calculated residuals are displayed. The highest residual for each element is flagged, along with any which exceed the limits set in step 1.3. Press F4 <More> to view the height element. If any changes need to be made, then press the back  button to return to the match screen.</p> <p>If the residuals are satisfactory, F3 <result> to view the transformation results (see 1.10), or F1 <OK> to store the coordinate system (go to (1.11)).</p>	 <table><thead><tr><th>WGS84 pts</th><th>East[m]</th><th>North[m]</th></tr></thead><tbody><tr><td>STN1</td><td>-0.003</td><td>0.003</td></tr><tr><td>STN2</td><td>0.001</td><td>-0.010!</td></tr><tr><td>STN3</td><td>-0.005</td><td>0.002</td></tr><tr><td>STN4</td><td>0.008!</td><td>0.002</td></tr><tr><td>STN5</td><td>0.003</td><td>0.000</td></tr><tr><td>STN6</td><td>-0.004</td><td>0.002</td></tr></tbody></table>	WGS84 pts	East[m]	North[m]	STN1	-0.003	0.003	STN2	0.001	-0.010!	STN3	-0.005	0.002	STN4	0.008!	0.002	STN5	0.003	0.000	STN6	-0.004	0.002
WGS84 pts	East[m]	North[m]																					
STN1	-0.003	0.003																					
STN2	0.001	-0.010!																					
STN3	-0.005	0.002																					
STN4	0.008!	0.002																					
STN5	0.003	0.000																					
STN6	-0.004	0.002																					
1.11	<p>This screen shows the transformation parameters.</p>	 <table><tbody><tr><td>Shift dX:</td><td>2029.2783m</td></tr><tr><td>Shift dY:</td><td>1028.8063m</td></tr><tr><td>Rotation:</td><td>118916.38807"</td></tr><tr><td>Scale:</td><td>125.3555ppm</td></tr><tr><td>Rotation orgn X:</td><td>0.0001m</td></tr><tr><td>Rotation orgn Y:</td><td>0.0000m</td></tr></tbody></table>	Shift dX:	2029.2783m	Shift dY:	1028.8063m	Rotation:	118916.38807"	Scale:	125.3555ppm	Rotation orgn X:	0.0001m	Rotation orgn Y:	0.0000m									
Shift dX:	2029.2783m																						
Shift dY:	1028.8063m																						
Rotation:	118916.38807"																						
Scale:	125.3555ppm																						
Rotation orgn X:	0.0001m																						
Rotation orgn Y:	0.0000m																						
1.12	<p>A summary is displayed, and if the user wishes residuals to be distributed using a particular method, this can be defined in the Coord system tab. Otherwise press F1 <Store> to store the new</p>																						

coordinate system, attach it to the WGS84 job and return to the main menu.

Store Coordinate System

Summary Coord system

Name: 1STEP NORMAL

Transformation type: Onestep

No. of matched pts: 6

Largest residuals

Easting: 0.0081m

Northing: 0.0096m

Fn ABC 11:28

Store Page